Installation

The loudspeaker can be installed both on the ceiling and on a vertical surface. It is strongly recommended that the mounting surface is flat (not curved).



Ensure that the mounting surface is free from obstructions, pipes or studs, either in front and behind the surface.



Ensure the speaker is installed at a height above 2.30 meters, making it inaccessible to children and untrained personnel





The cable runs and cable pipes shall be set according to the loudspeaker system configuration. The cables must be of adequate quality, suitable for the installation's environmental conditions and with proper copper section to minimize power loss.

Remove the grill from the loudspeaker and keep it in a safe place.



- Position the cutout template and mark the surface accordingly.
- Drill a pilot hole, then cut all of the way around the circular outline with a cutting saw.





The input signal terminals of loudspeakers models GC5, GC5T, GC6, GC6T, GC8 I, GC8T I and GC8 S shall be provided by speaker output terminals of an amplifier classified ES2/PS2 according to IEC/EN 62368-1.



Common input wire (-) is BLACK. Signal wire (+): connect only one wire among the input taps wires.



Select the input tap wire according to:

- the voltage level of the line;
- the wattage required to produce the desired sound pressure level for your application, allowing for some additional headroom.




The sum of the power taps of the loudspeakers connected to the same line shall be 20% lower than the amplifier's wattage rating.

4 Pull the speaker wire out of the hole and connect it to the loudspeaker.






Insert the loudspeaker into the hole and tighten all the clamp screws with a Phillips #1 screwdriver.



Reposition the grill on the loudspeaker.







GC81

8" ceiling/in-wall 2-way full range loudspeaker

Two-Way Loudspeaker

70.7V / 100V Audio Transformer

Passive full range loudspeaker

8" coaxial ferrite magnet woofer

0.75" Titanium dome tweeter

50 Hz - 20 kHz (-10 dB)

90 dB (1W, 1m)

112 dB (peak)

Spring terminals

160 W (peak)

Nominal Impedance

Nominal Line Voltage

70 V line

Maximum required mounting depth

25 mm (0.98 in)

2,04 kg (4.5 lb)

T Max 35°C

Ø 258 mm (Ø10.1 in)

130°

8Ω


8" Ceiling/In-Wall

To ensure proper operation, please carefully read this owner's manual and safety instruction before using the product. After reading this manual, be sure to keep it for future reference. For any further information, visit the website KGEAR.it.

Loudspeaker Wiring

Ensure that the amplifier is unplugged from the mains before making any connections.

Connect the input terminals of the loudspeakers to the speaker output terminals of the amplifier. Always check to ensure polarity is correct: L(left) to L, R(right) to R, "+" to "+", and "-" to "-"





Note: In case of sonic artifacts, roughness or distortion, reduce the signal volume to a lower setting. Never allow the amplifier to be driven into "clipping". Damage caused by operating the speakers at distorted volume levels is not covered by the warranty.

Warning. Failure to follow these safety instructions could result in fire, shock or other injury or damage to the device or other property.

IMPORTANT SAFETY INSTRUCTIONS

- Read these instructions.
- · Keep these instructions.
- · Heed all warnings
- Follow all instructions.
- · Installation and commissioning may only be carried out by qualified and authorized personnel.
- · Do not use this apparatus near
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on this apparatus.
- Prior to installing the speakers into any ceiling/wall, check the structure for weight bearing ability and avoid contact with any wiring or plumbing that might be behind the surface
- · Installing on soft materials or in areas incapable of supporting

the speakers' weight may cause personal injury or damage to the speaker.

- · Make sure the speaker is properly secured to the ceiling/wall. Please use the proper screws, bolts, or anchors. Failure to do so may cause the speaker to become unsecured and cause potential damages/
- · Damage to the woofer and tweeter or hit, resulting in no sound or
- the point of distortion and always reduce volume prior to switching input sources.
- Use only approved and certified wiring in your installation, do not stretch or place the wire in contact with sharp objects.
- · Prior to removing cables ensure all power to your amplifier and other components is turned off.

and regulations. Before putting the device into operation, please observe the respective country-specific regulations!

This device is in compliance with applicable CE standards

Packing List

Upon arrival, carefully inspect the shipping carton, then examine and test your new amplifier. If you find any damage, immediately notify the shipping company. Check that the following parts are supplied with the product.

- · 8" loudspeaker
- · Circular or square grill according to the speaker model
- · Cutout template
- · This user quide

Lo-Z 8Ω Technical specifications

injuries.

may occur if the speaker is dropped distorted sound.

- · Never overdrive your speakers to

Power Handling TAP 4W				
Power Handling TAP 8W				
Power Handling TAP 16W				
Power Handling TAP 32W				
Handling & Finishes				
Dimensions (Ø outer [Ø inner] x H) Ø 277 [258] x 105 mm (Ø10.9 [10.1] x 4.1 in)				
Minimum required mounting depth 112 mm (4.4 in)				

GC81

GC8TI

Nominal Line Voltage

100 V line

WHI	TE	⊚ GC8T-RNW	GC8T-SQW		
1 1	Maximum SPL is calculated using a signal with crest factor.				
Ų					

GC8T-RNB

GC8-SQB

GC8-SQW

GC8T-SQB

BLACK

(12dB) measured at 1 m